




Voilé Splitboard Hardware Puck Set Installation



Parts Included

- ① 1 Puck Alignment Guide
- ② *4 Pucks
- ③ **2 Parallel Slot Discs
- ④ **2 In-line Slot Discs
- ⑤ 4 Rubber Puck Gaskets
- ⑥ 8 M6 x 10.7mm Pan-head Mounting Screws


* Not compatible with old Voilé Discs branded with this logo: Voilé
 ** Not compatible with old Voilé Pucks (see images below)

For more details concerning compatibility, visit:
http://www.voile.com/voile_tech_alert_splitboard_pucks.pdf




Disc Reference & Guide

The slots in both the In-Line Disc and The Parallel Disc are intentionally placed off center in relationship to the disk. Each disc is marked with the letters A and B to indicate the orientation of the disc. Rotating the disc 180 degrees will shift the position of your binding mount and may be necessary to achieve your desired stance. (See Figure 1)




(Figure 1)

It is recommended to use the In-Line Disc on your heel-side puck. The mark labeled B will mount you more heel-side, up to .25"/6.35mm. The mark labeled A will move your mount more toe-side. (See Figure 2)



(Figure 2)


It is recommended that you use the Parallel Slot Disc for the toe-side puck. The mark labeled B will move your mount towards the tail of the board. The mark labeled A will move you toward the tip. (See Figure 3)



(Figure 3)


Stance Width & Angles

1.) Locate Puck Alignment Guide, 4 Pucks, 4 Rubber Puck Gaskets, 2 Parallel Slot Discs, 2 In-Line Slot Discs and 8 M6x10.7mm Pan-Head Screws.
(See Figure 4)




(Figure 4)

2.) With interlocking hooks on tip and tail kept tight, mark where you want your stance on the board. Tip: Use a clamp to keep hooks tight. (See Figure 5 and 6)



(Figure 5)

3.) Place rubber gaskets on all 4 Pucks.
(See Figure 7)



(Figure 6)

4.) Place 2 assembled Pucks with gaskets into the Alignment Guide and place over your front foot stance mark. Use stance location window to ensure you're on your mark. (See Figure 8)



(Figure 7)

5.) Using a hard surface for setup, set your front foot first. With the Puck Alignment Guide centered over your stance mark, place an In-Line Slot Disc on your heel-side Puck at your desired angle and locate over appropriate inserts. (See Figure 9)



(Figure 8)



(Figure 9)

6.) Place a Parallel Slot Disc over your toe-side Puck at the same angle you placed the heel-side and locate over appropriate inserts. (See Figure 10)




(Figure 10)

7.) With Puck Alignment Guide pressed flat against your board, thread 4 M6x10.7mm Pan-Head screws in the appropriate inserts. Be cautious not to cross-thread the insert. Tighten firmly. (See Figure 11)



(Figure 11)

8.) Remove Puck Alignment Guide.
(See Figure 12)



(Figure 12)

9.) Slide your binding onto the Pucks. It should slide on with limited resistance. **DO NOT USE EXCESSIVE FORCE.** If your binding is too difficult to slide on, repeat step 7.



(Figure 13)

10.) Slide the pin through the toe of the Slider Track, checking for any slop between the Pucks and Slider Track. If there is movement of your binding, fore or aft, and/or your pin does not slide through easily, repeat steps 7-9. (See Figure 13)

11.) If your binding fits properly, keep it attached to the board and repeat steps 4-10 for your rear foot.